



Illustrated Parts List

Model Series

215800

TYPE NUMBERS
0015 through 4529.

TABLE OF CONTENTS

Air Cleaner	6
Alternator	9
Blower Housing	6
Camshaft	3
Carburetor	5
Controls	8
Crankshaft	3
Cylinder	2
Cylinder Head	4
Electric Starter	9
Engine Sump	2
Exhaust System	6
Flywheel	7
Fuel Supply	8
Gasket Set - Engine	4
Gasket Set - Valve	4
Governor Spring	8
Ignition	9
Intake Manifold	4
Kit - Carburetor Overhaul	5
Lubrication	3
Operator's Manual	2
Piston, Rings, Connecting Rod	3
Rewind Starter	9
Valves	4
Warning Label	2



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

1319 WARNING LABEL




REQUIRED when replacing parts with warning labels affixed.

1058 OPERATOR'S MANUAL



1036 EMISSIONS LABEL


1036A









Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.













Assemblies include all parts shown in frames.

04/16/2012













Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.










DC ONLY		DUAL CIRCUIT		5/9 AMP		TRI CIRCUIT	
474A	1059	474B	1059	474C	1059	474C	1059
							



NOTE: All stators use a No. 1119 mounting screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



215800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697377	Cylinder Assembly			2578, 2604, 3015,	23	698281	Flywheel
2	399265	Kit-Bushing/Seal (Magnetos Side)			3025, 3026, 3120,			Used on Type No(s).
3	797673	Seal-Oil (Magnetos Side)			3332, 3551, 3553,			0026, 0101, 0105,
4	697106	Sump-Engine (Used After Code Date 05100200).			3578, 3604, 4116,			0108, 0133, 0134,
		----- Note -----			4117, 4119, 4332,			0135, 0137, 0146,
		795940 Sump-Engine (Used Before Code Date 05100200).			4529.			0155, 0161, 0163,
		Must Use Kit 795940, Includes Sump And Counterweight.			----- Note -----			0191, 0324, 0331,
4A	697188	Sump-Engine (Used After Code Date 05100200).			797021 Crankshaft Used on Type No(s).			0332, 0335, 0604,
		Used on Type No(s).			2119.			0948, 1180, 1194,
		0116, 0121, 0125,			697390 Crankshaft Used on Type No(s).			1529, 1536, 2110,
		0131, 0160.			0114, 0115, 0116,			2117, 2120, 2507,
		----- Note -----			0117, 0119, 0120,			2551, 2604, 3026,
		795957 Sump-Engine (Used Before Code Date 05100200).			0121, 0122, 0123,			3120, 3133, 3134,
		Used on Type No(s).			0124, 0125, 0126,			3135, 3155, 3194,
		0116, 0121, 0131.			0129, 0131, 0132,			3332, 3551, 3604,
		Must Use Kit 795957, Includes Sump And Counterweight.			0133, 0134, 0135,			4119, 4155, 4332,
5	796183	Head-Cylinder			0137, 0138, 0139,			4529.
7	273280S	Gasket-Cylinder Head			0140, 0141, 0142,			----- Note -----
11	794683	Tube-Breather			0143, 0144, 0145,			698282 Flywheel
12	697110	Gasket-Crankcase (.015" Thick)			0146, 0147, 0148,			Used on Type No(s).
		(Standard)			0149, 0150, 0152,			2118.
13	690360	Screw (Cylinder Head)			0153, 0154, 0156,			693557 Flywheel
14	790560	Stud (Cylinder Head)			0157, 0158, 0159,			Used on Type No(s).
15	690946	Plug-Oil Drain (3/8" Standard)			0160, 0164, 0165,			0025, 0125, 0129,
16	796146	Crankshaft Used on Type No(s).			0167, 0169, 0170,			0132, 0140, 0142,
		0015, 0025, 0026,			0171, 0172, 0173,			0143, 0144, 0145,
		0101, 0105, 0108,			0174, 0175, 0177,			0149, 0150, 0152,
		0113, 0118, 0130,			0178, 0179, 0180,			0153, 0156, 0159,
		0161, 0162, 0163,			0182, 0185, 0186,			0169, 0170, 0173,
		0191, 0223, 0274,			0188, 0190, 0192,			0174, 0175, 0178,
		0313, 0314, 0334,			0324, 0331, 0333,			0179, 0182, 0186,
		0335, 0948, 1180,			0578, 0604, 1194,			0188, 0274, 0314,
		1529, 1536, 2110,			3124, 3133, 3134,			2114, 2119, 2467,
		2113, 2114, 2115,			3135, 3139, 3194,			3025, 4117, 4140,
		2116, 2117, 2118,			4120, 4123, 4140,			4146, 4149, 4156,
		2120, 2466, 2467,			4141, 4146, 4147,			4170.
		2507, 2551, 2553,			4149, 4156, 4158,			693556 Flywheel
					4160, 4164, 4170.			Used on Type No(s).
					797508 Crankshaft Used on Type No(s).			0117, 0131, 0147,
					0155, 3155, 4155.			0172, 4147.
			20	795387	Seal-Oil (PTO Side)			
			22	692125	Screw (Crankcase Cover/Sump)			

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23A	693555	Flywheel Used on Type No(s). 0015, 0114, 0115, 0116, 0118, 0119, 0120, 0121, 0122, 0123, 0124, 0126, 0138, 0139, 0141, 0148, 0154, 0157, 0158, 0160, 0162, 0164, 0165, 0167, 0171, 0177, 0180, 0185, 0190, 0192, 0223, 0313, 0333, 0334, 0578, 2116, 2466, 2553, 2578, 3015, 3124, 3139, 3553, 3578, 4116, 4120, 4123, 4141, 4158, 4160, 4164. 698283 Flywheel Used on Type No(s). 0113, 0130, 1194, 2113, 2115.		797010	Piston Assembly (.020" Oversize) Used on Type No(s). 0015, 0025, 0026, 0101, 0105, 0108, 0113, 0118, 0130, 0155, 0161, 0162, 0163, 0191, 0223, 0274, 0313, 0314, 0332, 0334, 0335, 0948, 1180, 1529, 1536, 2110, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2466, 2467, 2507, 2551, 2553, 2578, 2604, 3015, 3025, 3026, 3120, 3155, 3332, 3551, 3553, 3604, 4116, 4117, 4119, 4155, 4332, 4529.		792728	Piston Assembly (.020" Oversize) Used on Type No(s). 0114, 0115, 0116, 0117, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0129, 0131, 0132, 0133, 0134, 0135, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0158, 0159, 0160, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0324, 0331, 0333, 0578, 0604, 1194, 3124, 3133, 3134, 3135, 3139, 3194, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4158, 4160, 4164, 4170.
24	796335	Key-Flywheel		792307	Piston Assembly (Standard) Used on Type No(s). 0114, 0115, 0116, 0117, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0129, 0131, 0132, 0133, 0134, 0135, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0158, 0159, 0160, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0324, 0331, 0333, 0578, 0604, 1194, 3124, 3133, 3134, 3135, 3139, 3194, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4158, 4160, 4164, 4170.			
25	797009	Piston Assembly (Standard) Used on Type No(s). 0015, 0025, 0026, 0101, 0105, 0108, 0113, 0118, 0130, 0155, 0161, 0162, 0163, 0191, 0223, 0274, 0313, 0314, 0332, 0334, 0335, 0948, 1180, 1529, 1536, 2110, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2466, 2467, 2507, 2551, 2553, 2578, 2604, 3015, 3025, 3026, 3120, 3155, 3332, 3551, 3553, 3604, 4116, 4117, 4119, 4155, 4332, 4529.						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

215800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
26	797011	Ring Set (Standard) Used on Type No(s). 0015, 0025, 0026, 0101, 0105, 0155, 0161, 0162, 0163, 0191, 0332, 0334, 0335, 0948, 1529, 1536, 2110, 2113, 2114, 2115, 2116, 2117, 2118, 2120, 2466, 2467, 2507, 2551, 2553, 3015, 3025, 3026, 3120, 3155, 3332, 3551, 3553, 3578, 3604, 4116, 4117, 4119, 4155, 4332, 4529. ----- Note ----- 797011 Ring Set (Standard) (Used After Code Date 09041500). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604. 792306 Ring Set (Standard) (Used Before Code Date 09041600 and After Code Date 08090100). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604. 698375 Ring Set (Standard) (Used Before Code Date 08090200). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604.		797012	Ring Set (.020" Oversize) Used on Type No(s). 0015, 0025, 0026, 0101, 0105, 0155, 0161, 0162, 0163, 0191, 0332, 0334, 0335, 0948, 1529, 1536, 2110, 2113, 2114, 2115, 2116, 2117, 2118, 2120, 2466, 2467, 2507, 2551, 2553, 3015, 3025, 3026, 3120, 3155, 3332, 3551, 3553, 3578, 3604, 4117, 4119, 4155, 4332, 4529. 797012 Ring Set (.020" Oversize) (Used After Code Date 09041500). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604. 697120 Ring Set (.020" Oversize) (Used Before Code Date 09041600). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604.		792306	Ring Set (Standard) Used on Type No(s). 0114, 0115, 0116, 0117, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0129, 0131, 0132, 0133, 0134, 0135, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0158, 0159, 0160, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0324, 0331, 0333, 0578, 0604, 1194, 3124, 3133, 3134, 3135, 3139, 3194, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4158, 4160, 4164, 4170.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	792643	Ring Set (.020" Oversize) Used on Type No(s). 0114, 0115, 0116, 0117, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0129, 0131, 0132, 0133, 0134, 0135, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0158, 0159, 0160, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0324, 0331, 0333, 0578, 0604, 1194, 3124, 3133, 3134, 3135, 3139, 3194, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4158, 4160, 4164, 4170.	28	797013	Pin-Piston Used on Type No(s). 0015, 0025, 0026, 0101, 0105, 0155, 0161, 0162, 0163, 0191, 0332, 0334, 0335, 0948, 1529, 1536, 2110, 2113, 2114, 2115, 2116, 2117, 2118, 2120, 2466, 2467, 2507, 2551, 2553, 3015, 3025, 3026, 3120, 3155, 3332, 3551, 3553, 3578, 3604, 4116, 4117, 4119, 4155, 4332, 4529. ----- Note ----- 797013 Pin-Piston (Used After Code Date 09041500). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604. 697099 Pin-Piston (Used Before Code Date 09041600). Used on Type No(s). 0108, 0113, 0118, 0130, 0223, 0274, 0313, 0314, 0334, 1180, 2110, 2119, 2578, 2604.		697099	Pin-Piston Used on Type No(s). 0114, 0115, 0116, 0117, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0129, 0131, 0132, 0133, 0134, 0135, 0137, 0138, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0158, 0159, 0160, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0324, 0331, 0333, 0578, 0604, 1194, 3124, 3133, 3134, 3135, 3139, 3194, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4158, 4160, 4164, 4170.
27	698469	Lock-Piston Pin (Used After Code Date 02100300). ----- Note ----- 698138 Lock-Piston Pin (Used Before Code Date 02100400).				29	791633	Rod-Connecting (Standard)
						32	791118	Screw (Connecting Rod)
						33	792868	Valve-Exhaust (Chrome) (Used After Code Date 06120300). ----- Note ----- 695760 Valve-Exhaust (Used Before Code Date 06120400).
						34	791935	Valve-Intake
						35	691279	Spring-Valve (Intake)
						36	691279	Spring-Valve (Exhaust)
						37	697352	Guard-Flywheel
						37A	697626	Guard-Flywheel (Electric Start)

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

215800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
42	499586	Keeper-Valve	81	691178	Lock-Muffler Screw	118	698788	Jet-Main
43	691968	Slinger-Governor/Oil	93	690602	Bushing-Throttle Shaft			(High Altitude)
45	690564	Tappet-Valve	94	794146	Kit-Idle Mixture			(Used After Code Date
46	793880	Camshaft			(Walbro)			08121400).
50	591245	Manifold-Intake	94A	793610	Kit-Idle Mixture			----- Note -----
		(Used After Code Date			(Nikki)			791405 Jet-Main
		11120100).	95	691636	Screw			(High Altitude)
		----- Note -----			(Throttle Valve)			(Used Before Code
		796188 Manifold-			(Walbro)			Date 08121500 and
		Intake	95A	690718	Screw			After Code Date
		(Used Before Code			(Throttle Valve)(Nikki)			07122500).
		Date 11120200).	98	495800	Kit-Idle Speed			699898 Jet-Main
51	692137	Gasket-Intake			(Walbro)			(High Altitude)
51A	796081	Gasket-Intake	98A	695408	Kit-Idle Speed			(Used Before Code
53	591260	Stud			(Nikki)			Date 07122600).
		(Carburetor)	104	690525	Pin-Float Hinge	121	790031	Kit-Carburetor
		(Used After Code Date			(Walbro)			Overhaul
		11120100).	104A	694918	Pin-Float Hinge			(Walbro)
		----- Note -----			(Nikki)	121A	796184	Kit-Carburetor
		690227 Stud	105	231855S	Valve-Float Needle			Overhaul
		(Carburetor)			(Walbro)			(Nikki)
		(Used Before Code	105A	696136	Valve-Float Needle	125A	590399	Carburetor
		Date 11120200).			(Nikki)			(Used After Code Date
54	691148	Screw	106	690577	Seat-Inlet			08121400).
		(Intake Manifold)			(Walbro)(Gravity Feed)			----- Note -----
55	695130	Housing-Rewind			----- Note -----			794653 Carburetor
		Starter			691780 Seat-Inlet			(Used Before Code
56	695129	Pulley-Starter			(Walbro)(Pump Feed)			Date 08121500).
57	695131	Spring-Rewind Starter	108	691227	Valve-Choke	127	694524	Plug-Welch
58	695132	Rope-Starter			(Walbro)			(Walbro)
60	493926	Grip-Starter Rope	108A	698773	Valve-Choke	127A	690727	Plug-Welch
65	690759	Screw			(Nikki)			(Nikki)
		(Rewind Starter)	117	796079	Jet-Main	130	790024	Valve-Throttle
		(Used After Code Date			(Standard)			(Walbro)
		07040800).			(Used After Code Date	130A	698774	Valve-Throttle
		----- Note -----			08121400).			(Nikki)
		697725 Screw			----- Note -----	131	790901	Kit-Throttle Shaft
		(Rewind Starter)			794352 Jet-Main			(Walbro)
		(Used Before Code			(Standard)	131A	698776	Kit-Throttle Shaft
		Date 07040900).			(Used Before Code			(Nikki)
73		Screen-Rotating			Date 08121500 and	133	494381	Float-Carburetor
		(Used Before Code			After Code Date			(Walbro)
		Date 07040900).			07122500).	133A	694914	Float-Carburetor
		(No Longer Available.			699897 Jet-Main			(Nikki)
		See Reference 1005A			(Standard)			
		For Service Flywheel			(Used Before Code			
		Fan)			Date 07122600).			
74	697897	Screw						
		(Rotating Screen)						
75	690582	Washer						
		(Flywheel)						
78	691693	Screw						
		(Flywheel Guard)						
78A	690364	Screw						
		(Flywheel Guard)						
		(Electric Start)						

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
135A	698780	Tube-Fuel Transfer (Nikki)(Gravity Feed)	192	691986	Adjuster-Rocker Arm			796260 Spring-Governor
		----- Note -----	202	691841	Link-Mechanical Governor			Used on Type No(s).
		792022 Tube-Fuel Transfer (Nikki)(Pump Feed)	203	691381	Crank-Bell			0105, 0116, 0117, 0125, 0133, 0138, 0155, 0158, 0165, 0332, 0333, 1180, 2120, 2551, 2553, 3120, 3133, 3155, 3332, 3551, 3553, 4119, 4155, 4158, 4332.
137	281165S	Gasket-Float Bowl (Walbro)	205	691693	Screw (Bell Crank)			690576 Spring-Governor
137A	698781	Gasket-Float Bowl (Nikki)	209	792813	Spring-Governor			Used on Type No(s).
141	790902	Kit-Choke Shaft (Walbro)			0015, 0025, 0026, 0108, 0114, 0115, 0118, 0119, 0122, 0123, 0129, 0130, 0132, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0159, 0160, 0162, 0164, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0334, 0578, 0604, 0948, 2113, 2114, 2115, 2116, 2117, 2118, 2578, 2604, 3015, 3025, 3026, 3139, 3578, 3604, 4116, 4117, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4160, 4164, 4170.			216 691840 Link-Choke
		(Used After Code Date 07010700).			----- Note -----	216A	691281	Link-Choke (Bell Crank)
		Used on Type No(s).			691278 Spring-Governor			Used on Type No(s).
		0114, 0115, 0120, 0129.			Used on Type No(s).			0124, 0134, 0335, 3124, 3134.
141A	698778	Kit-Choke Shaft (Nikki)			792602 Spring-Governor			Used on Type No(s).
141B	790903	Kit-Choke Shaft (Walbro)			Used on Type No(s).			1194, 3194.
		(Used Before Code Date 07010800).						260902 Spring-Governor
		Used on Type No(s).						Used on Type No(s).
		0114, 0115.						0135, 0313, 0314, 0331, 3135.
141C	793386	Kit-Choke Shaft (Manual Choke)						260902 Spring-Governor
142	790025	Nozzle-Carburetor (Standard)						Used on Type No(s).
143	790028	Nozzle-Carburetor (High Altitude)						0124, 0134, 0335, 3124, 3134.
146	691639	Key-Timing						796261 Spring-Governor
186	794873	Connector-Hose						Used on Type No(s).
187	791805	Line-Fuel (10-1/4 Inches Long) (Formed)						1194, 3194.
187A	791806	Line-Fuel (21 Inches Long) (Formed)						216 691840 Link-Choke
187B	791766	Line-Fuel (15 Inches Long)(Cut To Required Length)						216A 691281 Link-Choke (Bell Crank)
187C	791745	Line-Fuel (23 Inches Long)(Cut To Required Length)						Used on Type No(s).
187D	791744	Line-Fuel (14 Inches Long)(Formed)						0025, 0026, 0119, 0120, 0121, 0123, 0124, 0131, 0143, 0144, 0145, 0148, 0149, 0152, 0153, 0154, 0157, 0159, 0161, 0164, 0175, 0179, 0185, 0186, 2114, 2116, 2117, 3025, 3026, 3124, 4116, 4117, 4120, 4123, 4149, 4164.
188	691693	Screw (Control Bracket)						217 695409 Spring-Choke Return
190	796174	Screw (Fuel Tank)						222 694042 Bracket-Control
								222A 694335 Bracket-Control
								Used on Type No(s).
								0149, 0164, 2119, 4119, 4149.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5497-15	Assemblies include all parts shown in frames.	04/16/2012
----------------	---	-------------------

215800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
227	691374	Lever-Governor Control ----- Note ----- 694339 Lever-Governor Control Used on Type No(s). 0149, 0164, 2119, 4149.	240A	691035	Filter-Fuel (Clear, 40 Microns) Used on Type No(s). 0025, 0026, 0108, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0123, 0125, 0126, 0129, 0131, 0132, 0133, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0160, 0162, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0182, 0185, 0186, 0188, 0190, 0192, 0332, 0333, 2110, 2113, 2114, 2116, 2117, 2118, 2119, 2120, 3025, 3026, 3120, 3133, 3139, 3155, 3332, 4116, 4117, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4155, 4156, 4158, 4160, 4164, 4170, 4332.	304A	796450	Housing-Blower (Compatible With Panel Style Filter) Used on Type No(s). 2119.
232	691842	Spring-Governor Link				304E	799012	Housing-Blower (Compatible With Canister Style Filter)
238	691843	Cap-Valve				305	697102	Screw (Blower Housing)
240	394358S	Filter-Fuel (White, 75 Microns) Used on Type No(s). 0015, 0105, 0108, 0113, 0122, 0124, 0130, 0134, 0135, 0137, 0143, 0157, 0161, 0163, 0180, 0191, 0223, 0274, 0313, 0314, 0324, 0331, 0334, 0335, 0578, 0604, 0948, 1180, 1194, 1529, 1536, 2115, 2466, 2467, 2507, 2551, 2553, 2578, 2604, 3015, 3124, 3134, 3135, 3194, 3551, 3553, 3578, 3604, 4119, 4529. ----- Note ----- 298090S Filter-Fuel Used on Type No(s). 0101.				305A	793376	Screw (Non-Grommet Style Blower Housing)
						305B	795891	Screw (Blower Housing To Intake Elbow)
						305C	799370	Screw (Grommet Style Blower Housing)
						306	697359	Shield-Cylinder ----- Note ----- 792911 Shield-Cylinder Used on Type No(s). 2119.
			261	697176	Screw (Control Slide)	307	691693	Screw (Cylinder Shield)
			265	691024	Clamp-Casing	309	693551	Motor-Starter
			267	794904	Screw (Casing Clamp)	310	690323	Screw (Starter Motor)
			268	691025	Casing-Control Wire (Cut To Required Length)	311	497608	Brush Set
			269	691026	Wire-Control (Cut To Required Length)	324	796308	Screen-Rotating (Used After Code Date 07040800).
			270	691027	Nut (Control Wire Casing)	333	799650	Armature-Magneto (Used After Code Date 11061600). ----- Note ----- 795315 Armature-Magneto (Used Before Code Date 11061700).
			271	691028	Lever-Control	334	691061	Screw (Magneto Armature)
			276	692255	Washer-Sealing			
			300A	796000	Muffler			
			300B	795997	Muffler Used on Type No(s). 0113, 0114, 0129, 0130, 0223, 0274.			
			304	796414	Housing-Blower (Black) (Panel Style)			

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
337	491055S	Plug-Spark (Resistor) ----- Note ----- 691043 Plug-Spark (EMS) Used on Type No(s). 0105, 0116, 0119, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0130, 0131, 0133, 0134, 0138, 0142, 0143, 0152, 0153, 0155, 0157, 0158, 0160, 0163, 0165, 0179, 0180, 0191, 0192, 0313, 0314, 0331, 0332, 0333, 0334, 0335, 0604, 1180, 1194, 1536, 2120, 3120, 3124, 3133, 3134, 3155, 3194, 3332, 4119, 4120, 4123, 4155, 4158, 4160, 4332. 792015 Plug-Spark (Resistor-EMS) Used on Type No(s). 0135, 0137, 0159, 0161, 2551, 2553, 3135, 3551, 3553.	373	691612	Nut (Ground Terminal)	455	695113	Cup-Flywheel
			383	89838S	Wrench-Spark Plug	456	695128	Plate-Pawl Friction
			385	694476	Screw (Fuel Pump)	459	281505S	Pawl-Ratchet
			385A	690297	Screw (Fuel Pump)	462	691261	Washer (Starter Cable)
			387	697090	Pump-Fuel (Includes Mounting Bracket) (Used Before Code Date 08073000).	474A	696578	Alternator (DC Only)
			387A	808656	Pump-Fuel (Used After Code Date 08072900).	474B	696459	Alternator (Dual Circuit)
			404	691691	Washer (Governor Crank)	474C	696457	Alternator (5/9 Amp. Regulated Or Tri Circuit)
			415	794903	Plug (Manifold)	501A	794360	Regulator (5/9 Amp.)
			415A	794129	Plug (Cover/Retainer)	501B	698315	Regulator (9 Amp. Battery-Less)
			431	697122	Elbow-Intake (Compatible With Panel Style Filter)	503	691532	Strap-Starter
			431B	797901	Elbow-Intake (EVAP) (Compatible With Canister Style Filter)	505	691251	Nut (Governor Control Lever)
			445	797007	Filter-Air Cleaner Cartridge (Flat Panel Style)	507	691972	Insulator
			445B	796032	Filter-Air Cleaner Cartridge (Canister Style)	510	693699	Drive-Starter
346	794845	Screw (Spark Arrestor)				513	692024	Clutch-Drive
356	697397	Wire-Stop ----- Note ----- 792910 Wire-Stop Used on Type No(s). 2119.				520	691084	Terminal-Ground
356A	398808	Wire-Stop				521	690581	Shield-Cable
356B	697089	Wire-Stop				523	699908	Dipstick
356C	399222	Wire-Stop				524	691032	Seal-Dipstick Tube
357	691483	Key-Drive Pulley						
358	796181	Gasket Set-Engine						
359	691077	Washer (Ground Terminal)						
363	19203	Puller-Flywheel						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

215800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																	
525	697184	Tube-Dipstick Used on Type No(s). 0015, 0101, 0105, 0113, 0122, 0124, 0130, 0134, 0135, 0137, 0143, 0157, 0161, 0163, 0180, 0191, 0223, 0274, 0313, 0314, 0324, 0331, 0334, 0335, 0578, 0604, 0948, 1180, 1194, 1529, 1536, 2115, 2466, 2467, 2507, 2551, 2553, 2578, 2604, 3015, 3124, 3134, 3135, 3194, 3551, 3553, 3578, 3604, 4119, 4529. ----- Note ----- 697085 Tube-Dipstick Used on Type No(s). 0025, 0026, 0108, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0123, 0125, 0126, 0129, 0131, 0132, 0133, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0160, 0162, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0182, 0185, 0186, 0188, 0190, 0192, 0332, 0333, 2110, 2113, 2114, 2116, 2117, 2118, 2119, 2120, 3025, 3026, 3120, 3133, 3139, 3155, 3332, 4116, 4117, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4155, 4156, 4158, 4160, 4164, 4170, 4332.	527	792167	Clamp-Tube	634A	698779	Spring/Seal Assembly (Nikki)	635	691909	Boot-Spark Plug	643	697155	Retainer-Air Filter ----- Note ----- 792909 Retainer-Air Filter Used on Type No(s). 2119.	654	690958	Nut (Carburetor)	670	796175	Spacer-Fuel Tank	676	795036	Deflector-Muffler (Side Out) Used on Type No(s). 0025, 0026, 0108, 0114, 0115, 0117, 0118, 0123, 0124, 0129, 0132, 0134, 0139, 0140, 0141, 0142, 0143, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0156, 0157, 0159, 0160, 0162, 0164, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0180, 0182, 0185, 0186, 0188, 0190, 0192, 0335, 0948, 1529, 1536, 2110, 2113, 2114, 2116, 2117, 2118, 2120, 3025, 3026, 3120, 3124, 3134, 3139, 4116, 4117, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4156, 4160, 4164, 4170, 4529.																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																		
526A	697088	Screw (Regulator)	552	697144	Bushing-Governor Crank				676A	396903	Deflector-Muffler (Direct Out) Used on Type No(s). 0116, 0122, 0125.																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																														</

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
677	690661	Screw (Muffler Deflector)	759	697392	Pin-Counterweight	843	697158	Sleeve-Lever
684	697157	Screw (Breather Assembly)	773	796448	Retainer	847	790442	Dipstick/Tube Assembly
687	697175	Slide-Control	783	693713	Gear-Pinion			Used on Type No(s).
688	690395	Cap-Friction	788	699347	Bracket-Fuel Pump (Used Before Code Date 08073000).			0015, 0101, 0105, 0113, 0122, 0124, 0130, 0134, 0135, 0137, 0143, 0157, 0161, 0163, 0180, 0191, 0223, 0274, 0313, 0314, 0324, 0331, 0334, 0335, 0578, 0604, 0948, 1180, 1194, 1529, 1536, 2115, 2466, 2467, 2507, 2551, 2553, 2578, 2604, 3015, 3124, 3134, 3135, 3194, 3551, 3553, 3578, 3604, 4119, 4529.
689	691855	Spring-Friction	789	698329	Harness-Wiring			----- Note -----
689A	690529	Spring-Friction Used on Type No(s). 0114, 0115, 0129, 0190, 2113, 2115.	797	693167	Nut (Brush Retainer)			790443 Dipstick/Tube Assembly
691	692407	Seal-Governor Shaft	801	691283	Cap-Drive			Used on Type No(s).
692	691301	Spring-Detent	802	691286	Cap-End			0025, 0026, 0108, 0114, 0115, 0116, 0117, 0118, 0119, 0120, 0121, 0123, 0125, 0126, 0129, 0131, 0132, 0133, 0138, 0139, 0140, 0141, 0142, 0144, 0145, 0146, 0147, 0148, 0149, 0150, 0152, 0153, 0154, 0155, 0156, 0158, 0159, 0160, 0162, 0164, 0165, 0167, 0169, 0170, 0171, 0172, 0173, 0174, 0175, 0177, 0178, 0179, 0182, 0185, 0186, 0188, 0190, 0192, 0332, 0333, 2110, 2113, 2114, 2116, 2117, 2118, 2119, 2120, 2467, 3025, 3026, 3120, 3133, 3139, 3155, 3332, 4116, 4117, 4120, 4123, 4140, 4141, 4146, 4147, 4149, 4155, 4156, 4158, 4160, 4164, 4170, 4332.
697	791680	Screw (Drive Cap)	823	698941	Screw (Muffler Adapter)			
705	790561	Nut (Fuel Tank)	830	691095	Stud-Rocker Arm			
718	690959	Pin-Locating	832	790293	Guard-Muffler			
725	690403	Shield-Heat	836	690367	Screw (Muffler Guard)			
729	691335	Clip-Wire (Wire Retainer)	842	691031	Seal-O Ring (Dipstick Tube)			
729A	691224	Clip-Wire (Starter Motor)						
741	697128	Gear-Timing						
750	790832	Screw (Oil Pump Cover)						
757	793242	Link-Counterweight						
758	697391	Counterweight (Used After Code Date 05100200). ----- Note ----- 697391 Counterweight (Used After Code Date 05100200). Used on Type No(s). 0116, 0121. 795940 Counterweight (Used Before Code Date 05100300). Must Use Kit 795940, Includes Sump And Counterweight. 795957 Counterweight (Used Before Code Date 05100300). Must Use Kit 795957, Includes Sump And Counterweight. Used on Type No(s). 0116, 0121.						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

215800

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
850	100106	Sealant-Liquid (Rocker Cover Gasket and Breather Gasket)	972	799111	Tank-Fuel (Fluorinated) Used on Type No(s). 0177, 0178, 0179, 0182, 0186, 0190, 0192, 4117, 4120, 4140, 4141, 4146, 4147, 4149, 4156, 4164, 4170. ----- Note ----- 792168 Tank-Fuel (Standard)	1026	794573	Rod-Push (Exhaust) ----- Note ----- 697394 Rod-Push (Intake)
851	692424	Terminal-Spark Plug				1027	492932S	Filter-Oil (Standard)
864	796002	Adapter-Muffler (Length 2.25 Inches)				1029	691751	Arm-Rocker
868	690968	Seal-Valve				1034	690822	Guide-Push Rod
877	393456	Wire/Connector- Alternator (Dual Circuit)				1036		Label-Emissions (Available From A Briggs & Stratton Authorized Dealer)
877A	393814	Wire/Connector- Alternator (DC Only)				1036A		Label-Emissions
877B	393537	Wire/Connector- Alternator (Tri Circuit)	975	495933	Bowl-Float (Walbro)	1040	698368	Plate-Trim (Black)
877D	790544	Harness-Wiring	975A	698783	Bowl-Float (Nikki)	1040A	697381	Plate-Trim (Black)
878	398661	Harness-Alternator (Dual Circuit)	977	690192	Gasket Set-Carburetor (Walbro)			Used on Type No(s). 0604, 0948, 2507, 3604.
878A	691955	Harness-Alternator (5/9 Amp Regulated Or Tri Circuit)	987	691326	Seal-Throttle Shaft (Walbro)	1044	698139	Screw (Flywheel)
883	692236	Gasket-Exhaust	987A	698777	Seal-Throttle Shaft (Nikki)	1051	691265	Ring-Retaining
914	691108	Screw (Rocker Cover)	994	794945	Spark-Arrestor	1054	280275	Tie-Cable
918	791851	Hose-Vacuum (Molded)	1005	796082	Fan-Flywheel (Used After Code Date 07040800).	1058	276344	Operator's Manual
943	690589	Seal-O Ring (Oil Pump Cover)	1005A	796200	Fan-Flywheel (Used Before Code Date 07040900).	1059	698516	Kit-Screw/Washer
949A	799358	Guard-Debris Screen	1005B		Fan-Flywheel (No Longer Available) (See Reference 1005A For Service Flywheel Fan).	1070	791680	Screw (Flywheel Fan) (Used Before Code Date 07040900).
950	691657	Screw-Float Bowl				1070A	690363	Screw (Flywheel Fan) (Used Before Code Date 08061900 and After Code Date 07040800).
957	799719	Cap-Fuel Tank (Carbon In Cap) Used on Type No(s). 0177, 0178, 0179, 0182, 0186, 0190, 0192, 4117, 4120, 4140, 4141, 4146, 4147, 4149, 4156, 4164, 4170.	1017	796981	Screen-Oil Pump Used on Type No(s). 0116, 0121, 0125, 0131, 0160.	1090	691293	Retainer-Brush
957A	795027	Cap-Fuel Tank (Standard)	1022	272475S	Gasket-Rocker Cover (Used Before Code Date 07091000). (After Date Code Use Liquid Sealant Reference 850)	1091	691333	Cap-Limiter
958	698183	Valve-Fuel Shut Off (Plastic)				1095	796189	Gasket Set-Valve
964	799159	Cap-Connector (EVAP)				1119	691183	Screw (Alternator)
965	499613	Cover-Oil Pump	1023	797421	Cover-Rocker	1127	695407	Screw (Float Bowl)
967	697292	Filter-Pre Cleaner	1024A	794644	Pump-Oil Used on Type No(s). 0116, 0121, 0125, 0131, 0160.	1136	792629	Screw (Control Bracket)
968	697420	Cover-Air Cleaner (Black)						
968B	799016	Cover-Air Cleaner (Black)						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1139	796449	Washer	1267	697419	Latch-Blower Housing (Black)	1319	794467	Label-Warning
1146	793380	Screw (Choke Shaft) (Manual Choke)	1270	793243	Plug-AVS Counterweight (Used After Code Date 06081300).	1448	690260	Washer (Armature)
1263	697124	Reed-Breather			----- Note -----			
1264	697104	Screw (Breather Reed)			697156 Plug-AVS Counterweight (Used Before Code Date 06081400).			
1266	691917	Seal-O Ring (Intake Elbow)						
1266A	697123	Seal-O Ring (Intake Elbow)						

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

Not for
Reproduction

Not for
Reproduction

Not for
Reproduction

